## REPLACING GASKET ON BOMAR HATCHES AND PORTS

## **LIP GASKET**

(part numbers P2000-25, P2000-26, P2000-09)

- 1. Pull out all old gasket.
- 2. Starting near a hinge, gently push the lip of the gasket into the space between the lens and extrusion.
- 3. Carefully cut gasket to length forming a butt joint.
- 4. Pull out two inches of gasket either side of joint. Superglue joint together. Be careful not to get superglue on the lens. Allow glue to set for five minutes.
- 5. Push gasket joint into cavity.
- 6. Apply a drop of glue in four corners as shown in the diagram below. (the gasket shown below is for demonstration, it does not represent all gaskets)

