

SEADOG LINE

O.D.: 1-1/4" x 1-1/2" x 9"
9 ILLUMINATING SWITCHES
30 AMPS MAXIMUM PER PANEL
10 SPMS MAXIMUM PER CIRCUIT
10A V 21

VERTICAL SWITCH PANEL

Aluminum

1 EACH
110-11274


Sec-Dog Aluminum Vertical Switch Panels
Model #422110-1
Installation Instructions

1. Connect the positive terminal of the battery (12V only) to the bar identified with a "+" tag.
2. Connect the negative terminal of the battery (or ground) to the bar identified with a "-" tag.
3. Connect the positive wire of each individual circuit to the #2 spade on the corresponding rocker switch on the panel.
4. Connect the remaining wire or negative wire of each circuit to the common ground of the boat. If so equipped, or directly to the negative terminal of the battery or the negative bar of the panel.
NOTE: Do not attach any additional wires to the remaining terminal on the fuse holder.
5. Your Sec-Dog switch panel is supplied with 8 fuses - (2) 3A, (4) 5A and (2) 10A. (WARNING: Do not use fuse rated over 10A).
6. To remove the fuse holder cap, see figure 2 on opposite side.

FIG. 2




PUSH \blacktriangle indicates slot in the fuse holder body




Insert a ball point pen or small screwdriver in the slot. Press toward fuse holder.
CAUTION: FUSE POPS UP. Cover fuse cap with hand or finger. NOTE: DO NOT PLY UP THE fuse holder. You will break the fuse holder bracket!



Cap pops out. Insert or remove fuse, then snap cap back to position.



A - 6-1/2"
B - 4-1/2"



C - 5-1/2"
D - 3-1/2"

0P42201-1
420501-1
420441-1

Replacement Insert for Fuse Holder
Replacement Fuse Holder - Complete
Replacement Rocker Switch

VERTICAL SWITCH PANEL

- Marine Grade Aluminum Panel with 6 Illuminating Switches and 6 Fuse Holders.
- Includes 8 Fuses: (2) 3 Amp, (4) 5 Amp, and (2) 10 Amp.
- Customize with Included Labels.



Made in Taiwan

FIG. 1

